

Instructions:

- 1) Find and mark the center of your quilt top before loading. I like to
- 2) Load Quilt Sandwich as you normally would. Baste with tack stitches, or computerized basting pattern so that quilt sandwich is tacked approximately every 6 inches. You may use any thread you like for basting, but I prefer dissolving thread for basting ( Fil-Tec Perish ) so that I can stitch over basting without having to worry about taking it out later. It will dissolve during the first washing, or when blocking the quilt. It's very important to stabilize the quilt, especially when sewing patterns that are larger than the space between the rollers.
- 3) When stitching, align, bottom center of section 1 to center of quilt top.  
Sew section 1 first. Roll quilt sandwich backward to sew section 2, advance quilt and rotate section 2 180 degrees. Sew the rotated section 2. Roll quilt sandwich backward to sew section 3, then rotate section 3, advance quilt sandwich & Section 3 pattern. Sew section 3. Repeat these steps from \* replacing section 3, with section 4, & so on, through all the sections needed.
- 4) Add background quilting if desired.
- 5) Remove basting stitches, trim & bind as desired.

